OWNER'S MANUAL





Introduction, registration form, receipt document	
General specifications, drawings	
Information "before you go sailing"	
Operating the Swing Wing system	
Launch and assembly information	
Sail and trim tips	
Centreboard and rudder kick-up system	
Installations: water, toilet, pumps, transducers, seacock	
Installations: fuel, gas, heating	
Maintenance and product information	1
Rope diagram	1
Electrical diagram	1
Owner's List, Declaration of Conformity	1
Some of the warranty papers on boat parts	1
Extras	1

Introduction

We are delighted to welcome you to the family of DRAGONFLY sailors with our warmest congratulations on your new DRAGONFLY.

This manual is meant to help you enjoy sailing and understand the comfort and safety of your boat. The manual describes the boat, the equipment and includes maintenance guidance. Before you and your crew take off to sea, we strongly recommend reading the manual carefully to avoid any mistakes and/or damages. Make yourself at home onboard your boat before going sailing.

We keep improving our boats as we want you to benefit from new technology and breakthroughs, new equipment, materials and, of course, our experience. Therefore, the characteristics and information hereby provided are not binding and can be changed without prior notice or updated obligation.

DRAGONFLY is built with more than 50 years of experience in multihulls, and we feel today that we are delivering a consistent product of high quality and design. Quorning Boats endeavours to deliver a perfect product. If minor problems should occur, we kindly ask you to contact your dealer.

Please keep your DRAGONFLY in respectable condition as well at sea as ashore.

We wish you, your family and crew all the best and lots of fun with your DRAGONFLY 32.

QUORNING BOATS Aps

Jens & Peter Quorning
Dragonfly Trimarans

Denmark

Registration form

Type of boat:	Dragonfly 32 Swing Wing (Trimaran sailboat)	
CE-certification:	Category A / B	
Date of delivery:		
Name of boat.		
Homeport:		
Owner's name and address		
Name:		
Address:		
City:		
Country:		
Registration No		
Hull No:		
Hull ID-No:		
Engine serial No:		
YOUR DEALER:		

QUORNING BOATS ApS

Skærbækvej 101, DK-7000 Fredericia, Tel. + 45 75 56 26 26, info@dragonfly.dk

Document and receipt for Dragonfly 32

Hull No:	Hull ID-No:
Owner's name and	address
Name:	
Address:	
City:	
Country:	
	thereby certifies that I have accepted delivery and read thowner's Manual delivered with the boat – before using the boat.
Date:	Signature:
Hull No:	Hull ID-No:
Owner's name and	address
Name:	
Address:	
City:	
Country:	
	thereby certifies that I have accepted delivery and read th Owner's Manual delivered with the boat – before using the boat.
Date:	<u>.</u> Signature: <u>.</u>

Before use of the craft, please return this slip to:
QUORNING BOATS ApS, Skærbækvej 101, DK-7000 Fredericia.
If not, Quorning Boats ApS cannot be held responsible of any kind of damage or injury.

General specifications

DRAGONFLY 32 TOURING

Length overall centre hull	9.80	m
Length waterline centre hull	9.50	m
Length folded	11.99	m
Length sailing	9.80	m
Beam sailing	8.00	m
Beam folded	3.60	m
Draft	0.50	m
Draft, incl. centreboard	1.90	m
Weight of standard boat, incl. sails and engine	3,400	kg
Payload max, incl. crew	1,200	kg
Max total weight, excl. crew	5,110	kg
Water tank	120	litres
Holding tank (optional)	60	litres
Fuel tank, diesel	70	litres
Engine, inboard	21	Нр
Mast section total, excl. antennas	14.70	m
Mast height over water level	16.50	m
Mainsail	48	m^2
Standard genoa	26	m^2
Asymmetric spinnaker	95	m^2
Code 0		2
	57	m²


CE-Design category	Α
Max No of persons in category A	5
CE-Design category	В
Max No of persons in category B	7

General specifications

DRAGONFLY 32 EVOLUTION


Length overall centre hull	9.90	m
Length waterline centre hull	9.50	m
Length folded	11.99	m
Length sailing	9.90	m
Beam sailing	8.25	m
Beam folded	3.85	m
Draft	0.50	m
Draft, incl. centreboard	1.90	m
Weight of standard boat, incl. sails and engine	3,450	kg
Payload max, incl. crew	1,200	kg
Max total weight, excl. crew	5,110	kg
Markey keyels	100	litres
Water tank	120	iities
Holding tank (optional)	60	litres
Holding tank (optional)	60	litres
Holding tank (optional) Fuel tank, diesel	60 70	litres litres
Holding tank (optional) Fuel tank, diesel Engine, inboard	60 70 21	litres litres Hp
Holding tank (optional) Fuel tank, diesel Engine, inboard Mast section total, excl. antennas	60 70 21 16.70	litres litres Hp m
Holding tank (optional) Fuel tank, diesel Engine, inboard Mast section total, excl. antennas Mast height over water level	60 70 21 16.70 18.50	litres litres Hp m
Holding tank (optional) Fuel tank, diesel Engine, inboard Mast section total, excl. antennas Mast height over water level Mainsail	60 70 21 16.70 18.50 58	litres litres Hp m m m
Holding tank (optional) Fuel tank, diesel Engine, inboard Mast section total, excl. antennas Mast height over water level Mainsail Standard genoa	60 70 21 16.70 18.50 58 29 110	litres litres Hp m m m² m²

CE-Design category	Α
Max No of persons in category A	5
CE-Design category	В
Max No of persons in category B	7





Side-view

Dragonfly 32














Before you go sailing

CHECK LIST

- Check the weather forecast carefully.
- Check water tank level.
- Check fuel tank level.
- Check the power on your batteries are adequate.
- Check engine oil (and cooling water on the Diesel engine).
- Check and make sure that the water intake filter to the Diesel engine is clean and full functional.
- When starting up the Diesel engine (optional), check and make sure that cooling water is coming out of the exhaust system at the transom (if not, check that sea cork for engine water intake is open – and not blocked) If not, stop the engine.
- For Outboard engine also check cooling water is working perfect by the smaller cooling water outlet higher up on the engine.
- Check that you have enough propane for cooking (for longer trips).
- Make sure that all equipment is stowed correctly and has been secured well.
- · Check that water stays and rigging are fully intact.
- Check that ALL hatches + window/escape hatch in the aft cabin, are fully and secure closed – especially on the floats.
- If the boat is new, please note that on delivery, electronics and autopilot systems are not calibrated when the boat leaves the yard and GPS Plotter is not supplied with GPS chart chip.
- Regularly check all the bilges in all 3 hulls for water.

IMPORTANT NOTICE

BEWARE OF THE FOLLOWING

- Make sure that there always are lifejackets and/or life preservers onboard for the whole crew – and use them!
- Always as minimum, we strongly recommend using lifebelts/harness outside the cockpit when sailing or even motoring at night.
- No persons are allowed on neither trampolines, wings, nor floats when sailing offshore in strong wind conditions.
- High tension/voltage cables. Mast height above sea level is 18.5 metres/62 feet with no antennas.
- For Ocean crossings, we recommend carrying a life raft in case of fire.
- For Ocean crossings and long distance offshore sailing we recommend all crew to get familiar with the safety hatch in the aft cabin and the function of this, make sure while sailing that the safety hatch is secure closed but NOT LOCKED with the red buttons on the inside of the hatch.
- In case of capsize stay calmly inside the boat and if necessary, you can
 get out via the safety hatch in the aft cabin hull side. DO NOT try to dive
 out elsewhere from the boat, as the risk of getting caught in ropes
 hanging down in the water is too risky.
- By long distance sailing, make sure that all on board are aware of the above-mentioned procedures.
- Make sure to have a knife accessible both inside and outside.
- For long distance sailing or Ocean crossings, make sure to have up-todate flayers and other safety devices, like Epirp etc.
- For longer crossings carry on board e.g. extra impellers, fuel and diesel filters and belts for the engine, and maybe spare parts and filters for the water maker if this is installed on board. Also, make sure to have good strong batteries and safe power supply.

- Make sure that all heavy gear inside the floats is tied well down, so this cannot damage and puncture the floats and cause leaking problems.
- Make sure and check that anchor equipment is secured well and even tie an extra security line on the anchor when you meet rough conditions.
- Always check that float hatches are closed, also while sailing.
- For long-distance sailing, we recommend installing "Jackstay's", a safety lifeline in e.g. webbing materiel to hook on to when going on deck. If this is installed, make sure this is installed correctly, so that you don't fall overboard but stay on the boat in combination that you harness/lifeline is not too long.
- Please be aware that the trampolines can be slippery when wet, and/or in cold conditions. Further, the trampolines are extra slippery when not pulled tight enough.
- Never walk or be on the leeward trampoline, and/or on the leeward float when sailing upwind and beam reach in +8 knots true windspeed.
- In strong wind conditions, we recommend staying on the centre hull only.

IMPORTANT – always make sure that other crew members onboard have been instructed in how to start up the engine and take sails down and have been instructed on how to pick up a person who has fallen overboard – could e.g. be the skipper who fell overboard!

Make sure your horseshoe lifesaver is in good condition and that the light for this is working.

Check that you have a floating line on board, to throw to a person in the water, e.g. the mooring lines supplied with the boat when it is new, is floating lines!

We do normally not recommend trying to rescue people in the water with sails up.

Be careful that the person in the water do not get close to the propeller.

If you fail to get a person on board, you can also use a halyard, like spinnaker halyard to pull a person on board.

CONTROLLING THE BOAT

If this is your first multihull, we highly recommend getting some training in controlling the boat while sailing as well as motoring (manoeuvring) before taking command and control over the vessel, to ensure your safety and comfort. THIS IS VERY IMPORTANT.

Your dealer will give you this first basic information. We strongly advise when receiving the boat, to get to know the boat well first under easy calm conditions, especially also manoeuvring the boat under engine, try this out e.g. in open water, by first using a fender or similar and manoeuvre the boat around this floating object, get to learn how the boat turns, stops and how it manoeuvres in reverse etc. This is a very important exercise.

To make good manoeuvres under engine, you ned to use more power to get the boat turning etc. and the better you know how to handle the boat – the much more fun it also is.

This boat is not more difficult to handle than a conventional yacht and many times easier, but it behaves a bit differently. The propeller is when the boat is folded very close to the water line, therefore going into reverse is not as efficient as you may expect. Therefore, do not hesitate to use power in reverse. First gently to get good propeller grip in the water and then use more power. This problem is relevant when wind push you from astern.

IMPORTANT – When the boat is in folded position, the boat and propeller is lifted 8 to 9 cm higher and, when folded, the propeller has even less effect. Test this out well in controlled conditions, so you really get familiar with this. For your information, the engine can motor against the wind in up to 30 knots true wind on flat water and against waves up to 25 knots of wind. If you need

to motor against stronger winds, we recommend assisting with only a bit of jib to assist. (no sails if folded).

We recommend starting up sailing with max. 4 Beaufort = 20 knots of true wind till you feel fully comfortable in controlling the boat.

VERY IMPORTANT – Always, before taking the boat out: Pull the centre board fully down for better manoeuvring, without the centre board down, the boat cannot make a sharp turn and will drift much quicker, also powered by engine. And again, check that all float hatches are closed safely.

NEVER set sails before both floats are folded OUT to full beam and backstays are set tight and safety cables are installed on the aft wings.

When folded in, please avoid stronger wind and waves from the side.

CLASSIFICATION

The DRAGONFLY 32 is classified according to the CE-standards in category **A** and **B** with different number of persons allowed on board.

DRAGONFLY 32 is designed for the CE category **A** Offshore and Ocean trips with max 5 persons onboard, during which the wind may rise to more than max 8 Beaufort on the Beaufort scale = 40+ knots = 20+ m/sec. true wind and the waves may rise to more than 4 m significant wave height.

For CE-certification category **B** you can also sail offshore with max 7 persons onboard, during the wind may rise to max 8 Beaufort (40 knots/20 m/sec of true wind) and waves may rise to max 4 m significant wave height.

The Dragonfly 32 is certified for the CE by notified organisation (body) IMCI No 0609 under the design module A – internal factory control and external control of buoyancy, stability, and flotation.

The provided wind/sail diagram must under all circumstances be respected.

For long distance offshore sailing and ocean crossings, we strongly recommend the skipper and crew to be quite experienced sailors.

The Dragonfly 32 can well be sailed singlehanded – but this requires extremely good sailing skills and experience.

MANOEUVRING AND MOORING RECOMMENDATIONS IMPORTANT NOTICE

Always wear your life jacket when sailing or even motoring.

In heavy weather, always wear the safety harness on deck.

Make sure to have functional life jackets for the whole crew.

When sailing in windy conditions, stay on the centre hull only.

Minimum four mooring lines of adequate dimensions (min 14 mm x 14 metres) and suitable for the environment should be on board.

- Always only manoeuvre the boat by the engine in harbour areas NO sails.
- Handle the boat consistent with the current and wind.
- Protect the boat with suitably sized fenders.
- Always keep the ropes unfold and home.
- Handle the boat at slow speed in harbour 2 to 4 knots.
- Beware it can be difficult to stop the boat downwind especially when the boat is folded, where the propeller is closer to the water surface.

DANGER

Never try to stop the boat with your foot, your hand, or a boat hook.

When moored:

- Protect the ropes from chafing with for example plastic sleeves.
- Take possible tides into account.
- Always tie the fore and aft dock lines from the main hull ONLY, folded or not folded.
- Always make sure to use 2 spring lines on the boat alongside a dock.

PRECAUTION

- Be well acquainted with the boat before going sailing in more than 5
 Beaufort true wind (20 knots 10 m/sec).
- Learn to handle the boat well under power and to make safe harbour manoeuvring – note that sometimes it can be difficult to stop the boat in reverse downwind.
- Be aware that the boat maybe can capsize in folded condition by winds exceeding 8 Beaufort (40 knots 20 m/sec). In that case secure the boat/mast sideways, with e.g. one halyard to each side, this halyard don't have to be tight just loose/slack so tide is not a problem, or fold minimum one side out and/or both sides min each 75 cm (3") out, please note that this is only necessary by side winds.
- We do NOT recommend leaving the boat folded on a mooring or at anchor.
- Never moor the boat folded where wave heights exceed max 25 cm (10")
- Never let the boat dry out in folded position as the seabed can be angled.
- The boat is unsinkable at all times. If anything should happen, always stay with the boat.
- In capsized position the boat will stay afloat approx. at main cabin sofa seat level, if the floats are fully intact and full buoyant.
- By each wing base you will find a stainless eye for lifelines as well in the cockpit sides over the seats.
- For longer offshore passages, life raft is recommended, for example in case of fire.
- All three hulls have watertight crash bulkhead forward to prevent flooding
 of the hulls, if e.g. only the very front bow area gets damaged, only the
 forward section will be partly flooded.

 If Bow thruster (optional) is being used – ALLWAYS check there no lines hanging down in the water, like e.g. the tack line for the bowsprit or mooring lines, and make sure no persons are swimming close to the boat.

IMPORTANT USER INFORMATION

- When folding in or out in strong winds, motor <u>up into the wind or even</u> <u>better motor downwind</u>. In strong winds, only downwind, if you have waves.
- Never keep or motor the boat in folded condition where wave heights exceed max 10" or 25 cm, otherwise the folding system can get damaged and by bigger sideway waves (and wind) the boat can even capsize.
- Be aware that the boat can capsize if not handled correctly and sailing instructions are not followed.
- All sails must be down and secured well and safe BEFORE folding.

SAILING BY AUTOPILOT

- **IMPORTANT** Depending on the wind and wave conditions, using Autopilot in winds exceeding 10 m/secs (20 knots) true wind is difficult and boat must here be sailed much more conservative.
- Autopilot can be used in stronger winds, but only when reefed even more conservatively than our "sail to wind diagram".
- Quorning Boats cannot be held responsible for any damages or problems caused by sailing using Autopilot, as this at times can be unreliable.

IMPORTANT INFORMATION ON THE RIGGING

- Always check the rigging, halyards, reefing lines, water stays, rudder downhaul and swing-wing system before taking the boat out to sea.
- Every season or min. once a year shorten all halyards, reefing lines and swing-wing lines by approx. 20 cm/8", if you see signs of chafing on the line. After some years, you can, for example turn these lines around or

change these with new lines. If lines are changed, make sure to replace lines with the same quality of lines. Most of these lines are Dyneema quality.

- Standing and running rigging, we recommend changing every 10 years using the same quality of products. We recommend changing the water stays after 7 years and/or by max 15,000 NM of sailing.
- Mast rigging/diamond tension is set from the factory on new boats, never change this setting.
- Never use shackles or similar on the boats-man chair without back-up line tied.
- NEVER climb the rigging when the boat is in folded position.
- Tension on the rigging, please see rig diagram. The diamond stays must be checked minimum once a year according to tension diagram as well as before making long-distance trips.
- Never change the tension on the diamonds without checking tension with a tension meter according to rig tension diagram, changing the rig tension can cause the mast to break.
- Never drill holes in the carbon mast section without asking your dealer or Quorning Boats beforehand.
- NEVER wrap the mast in any plastic, as this can cause the paint to bubble up. If covering is needed, use only breathable textile materials.
- When stepping the mast, NEVER secure the mast sideways with only halyards in folding position, as the angle is too narrow – when folded out, it is OK.
- Regularly check that all shackles and blocks are tight and safe, also e.g. when
- The boat is new and rigged by the yard or dealer as shackles can quickly become loose.

OPTIONAL WHEEL STEERING

The cables on the wheel steering are set from the factory – but the cables can by more use become slacker – and must be tightened again later, simply by the terminal on the cable at the Rudder quadrant itself – simple to do.

If autopilot is used more frequent – this is very important as slack steering cables will make steering by hand and especially by autopilot unsafe.

Operating the Swing-Wing system

- IMPORTANT The Swing-Wing system must ONLY be used in protected harbour areas. Max. total wave height of 0.2 m. Any use elsewhere at owner's own risk.
- ALWAYS use the Swing-Wing system WITHOUT SAILS. The sails must NEVER be hoisted when the floats are folded in, or when operating the folding system.
- ALWAYS pack down and secure the sails safely well BEFORE you start
 operating the Swing-Wing system. Check the furling jib line is closed.
- **ALWAYS** point the boat into the wind when operating the Swing-Wing system, and, or even better point downwind in stronger winds.
- Max. boat speed in folded position under power is 6 knots more speed can damage the folding system.

PROCEDURE HOW TO FOLD OUT THE FLOATS

IMPORTANT - always fold only one side at a time

- 1) First take away all the fenders and mooring lines and stow these safely away.
- 2) Prepare the endless Swing-Wing line by the double halyard stopper on the side of the cockpit marked "FOLD IN" in and "FOLD OUT" and make sure the endless line has no kinks and can run freely.
- 3) Take the marked "FOLD OUT" line three turns around the electrical winch in front of the wheel or let the line just go around the bigger winch in front of the wheel and lead the line to the smaller mainsail winch closer to you.
- 4) Point the boat up into the wind. On flat water just under engine by about 3 knots boat speed for better course control of the boat.
- 5) Release and open (fully up) the tripple rope stopper on the cockpit side. The two halyard stopper handles are fixed together, so both lines ("FOLD OUT" + "FOLD IN") will be open at the same time. When you open the

halyard stopper, the float "shoots" about halfway out, so start quickly to activate the "FOLD OUT" line by hand or on the electric winch. If you are to slow, you might experience the Swing Wing line to kink. To prevent the float "shooting" out itself, you can hold some tension on the "FOLD IN" line.

- 6) The float will automatically start to fold out and you can now activate the electrical winch.
- 7) Keep an eye that lines do not jam between the wings and the main hull. Once again ensure that the endless Swing-Wing line has no kinks. Keep the "FOLD IN" line in your hand to prevent kinks, while folding out.
- 8) If something jams stop winching immediately and check if something prevents the Swing Wing system from folding out.
- 9) When the float is almost fully out, please focus and fold out the rest slowly controlled. Check that the trampoline is well tight. By continued too much use of the electrical winch, this can damage the Swing-Wing system, which is why you must winch the last bit out gently (on new boats there is a mark on the Swing-Wing lines that indicates when the floats are pulled fully out and or in).
- 10) Stop when the trampoline is nicely pulled out and tight or at the marking on the line you pull out. If the trampoline feels a bit too soft just gently tighten the "fold out" line a bit more. If not already done, we recommend marking the Swing Wing lines when it's fully tight and pulled out for faster operation.
- 11) **Now very IMPORTANT**, tighten and pull by hand only the slack of the backstay on the first same side that you just folded out.
- 12) Do the same fold out procedure on the other side **NEVER at the same** time only one side at a time.
- 13) Now tighten both backstay lines by the winch and check that both backstay lines are pulled approx. similar by checking visually the angle of the side stays/backstays this does not have to be 100% perfect. Tighten the backstays tight to the marking on the line, or, as much as you can easily pull with one hand on the winch handle.

- 14) **VERY IMPORTANT** When both sides have been folded out, always remember to secure and **fix the safety cables**. These safety cables are a vital part of the Swing-Wing system, which you will find at the outer back end of the trampoline, where you install the openable snap-shackle in the vacant steel eye on the forward outer end of the aft wing. This safety cable together with the Swing-Wing outhaul line system will always hold and secure the boat when the floats are fully pulled out. If these safety cables are not installed, the boat can fold in and collapse while sailing.
- 15) The safety cables are also as backup if someone should by accident open the rope clutch/halyard stopper for the Swing-Wing system or if the Dyneema line for the Swing-Wing system should fail over time.
- 16) **No persons** are allowed on the floats/amas and wings when operating the folding system. Keep hands away from the wing/hull joint and moving parts.

VERY IMPORTANT:

ONLY FOLD IN OR OUT, ONE FLOAT AT A TIME.

If both floats are folded in and/or out at the same time, there is a possible chance that the mast can fall over forward due to the extra slack in the side stays, when both floats are folded out at the same time with no tension on the side stays.

So, always fold only one float in or out and finish that one side (including pulling the backstay by hand when folding out) before you fold in or out the other side. Make sure also your crew is informed about this important information.

PROCEDURE TO FOLD IN THE FLOATS

Again, face the boat into the wind.

1) First release the safety cables on both port and SB-side at the outer end of the aft two wings. Set and lock both genoa sheets hand tight so the (optional) barber haul system does not get jammed if installed or disconnect the barber hauler block system by the openable Black/Yellow ANTAL block. Again, also check that the furling line to the genoa is closed/locked, so the Genoa cannot furl out again – and the mainsail is packed and lashed well and safe down, this is very important.

- 2) Prepare the endless Swing-Wing line by the double halyard stopper by the cockpit coaming and make sure that the line has no kinks.
- 3) IMPORTANT Release now ONLY the backstay in the same one side you are folding in; release the backstay slowly by easing the backstay line around a winch before you open the halyard stopper for the backstay, as you can burn your hands on this backstay line. Never open the backstay line under load just on the jammer, release by taking the load off over the winch and then open the halyard stopper and easy slowly and gently.
- 4) First, take the line marked "FOLD OUT" 2 or 3 turns around the electric winch, pull just a bit and you can now easily open the double stopper/jammer and release the line slowly, then you can change line around, so the "FOLD IN" line now is ready on the e-winch, make sure the barber hauler line and maybe also Code-O sheet lines are free to flow, so these don't jam.
- 5) The float can now be winched in towards the centre hull make sure that the Swing-Wing lines do not kink, and that the backstay line is **ALWAYS** open and slack and can run freely.
- 6) The water stays and the trampoline "takes care" of themselves. The trampoline will not get in touch with the water, so it is not necessary to pull them up.
- 7) **Immediately stop winching** in the float when the float touches the centre hull under the wings. Make an indication on the folding lines to remember this position. On new boats it is already indicated on the folding lines when the hulls are completely folded in. But pull slowly in at the end, so you do not overstress the folding lines and the block systems.
- 8) **IMPORTANT** Now also close the double rope jammer again before you take the Fold In line off the winch, otherwise the hull folds out again. Now one side is fully folded in.

- 9) When <u>both</u> floats are pulled in, pull the slack in the backstay lines tight by hand only to take up the slack. Normally this is not necessary.
- 10) Again, either the boat must face into the wind or even better go downwind. **Never** position the boat with wind and waves from the side.

We can also recommend marking the Swing-Wing inhaul line when this is pulled into the right IN position. This is done on new boats, but as lines are flexible, this can be a bit incorrect and is only an indication.

We are often being asked if you can have other boats tied up alongside in folded position – yes, this ok – but max 3 boats of max 40 feet. But only in protected areas like a closed harbour. If you have waves or often waves from bigger powerboats passing by – it is not recommended to have bigger yachts alongside. However, we do not recommend having very heavy Yachts tied up alongside. This also requires that all the boats are moored and tied up correctly.

When tied up alongside a dock – always remember to check if the water locally has tide and if the seawater level can or will change.

INFORMATION WHEN USING THE SWING-WING SYSTEM

Max tension on the backstays is ONLY what one person can pull by using one hand on the winch handle.

By sailing in stronger wind and wave conditions the leeward backstay will normally get slack – but only pull this slack by hand in the leeward side – never use the winch to leeward, as this can put too much stress and tension on the rigging and cause rigging failure.

The Swing-Wing system must not be operated in winds exceeding 12 m/s or 25 knots true wind speed in open areas and **NEVER** in any side winds exceeding 7 m/s or 14 knots true wind.

The boat will stay stable folded in a slip as long as waves are max 20 cm/8" and wind speeds from sideway do not exceed 20 m/s or 40 knots of true wind speed. If higher winds are expected either make sure the boat faces into the wind, or secure the mast sideways, by a halyard to the dock with lor 2 m slack

- or, in worst case (like heavy storm or hurricane warning), take the mast down or move the boat to a place, where it can be folded out. Or take the boat out of the water, take the mast down and secure the boat.

NEVER keep the boat folded on a mooring or at an anchor.

NEVER let the boat dry out in a folded position.

NEVER hoist any person up into the rigging when the boat is folded.

NEVER set any sails when folded.

Only use the Swing-Wing system in harbour or wave protected areas.

IMPORTANT

On dry land **NEVER** fold out by using the folding system only. On dry land, you have to push by hand the float approx. half the way out, before you winch it out with the swing-wing system. This is due the fact that the floats are missing their buoyancy from the water.

When folding in on dry land, it is **VERY important** to hold the "fold-out" line in your hand to control that the float does not fall in/down by itself. This can damage the boat, and people around the boat can be injured.

<u>ALWAYS</u> remember to install the safety cables before setting sails. If these are not installed, the boat can collapse while sailing. This is always the Skipper's responsibility.

When you fold in the hulls – remember to take note that the floats go backwards and makes the boat longer.

Swingwing-system

Dragonfly 32



End of line

End tied to block

Wing stop cable

Prevents folding out too far

Safety cable

Prevents folding in while sailing, to be manually set on-off when folding

Swingwing lines

8 mm Dynema, 27 meter endless

Swingwing cable

Inside trampoline, 6 mm, 483 cm

Rope clutches

Dubble rope clutch in cockpit handlocker

End of line

Line tied to hull

Snap shackle

Locks safety cable - Important!



Launching the boat

When launching, or handling the boat, for example for transport or winter storage, the lifting eyes and straps/slings are guaranteed to hold ONLY when provided from Quorning Boats and used under the following conditions:

SHORTER LIFTINGSTRAPS AFT AND LONGER FORWARD.

- 1) Lifting eyes and straps/slings are designed for single crane hook system use only not for individually use or use elsewhere, therefore all four straps to one crane hook = single point lifting.
- 2) Lifting straps/slings must not be used elsewhere or for other purposes.
- 3) When lifting, you must check and make sure that the lifting eyebolts are facing and line up with the lifting straps/slings. If not, this can cause break of the lifting eyes, and for this Quorning Boats cannot be held responsible.
- 4) Make sure that **NO PERSONS** are neither on nor under the boat when craning. If work must be done under the hull, make sure that your hull safety support can take the full load of the boat, if the lifting straps should fail.
- 5) The lifting straps are designed for the boat only NO crew onboard and the bilges MUST be empty. If the total weight exceeds 5000 kg/10,000 pounds, the straps should not be used.
- 6) No persons are allowed on the boat while craning.
- 7) **Before craning** the boat out of the water, make sure to lift up and secure the centreboard and release the rudder downhaul, so this can be lifted up when setting the boat down on the cradle.
- 8) When craning with the lifting straps, the boat **MUST always be in folded position**. The mast can also stay up no difference in the balance.
- 9) **IMPORTANT** before launching the boat, (also on a new boat) check that log and depth sounder transducers are fitted correctly in place to avoid flooding the centre hull. Travel lift can be used if this is not too small. Fold first the hulls a bit out. The belts should be mounted ONLY on the centre

hull forward of the forward crossbeam and aft of the aft crossbeam around the centre hull only. Be careful not to get the belt around the propeller if the boat has an inboard engine.

- 10) A travel lift can be used if this is not too small. First, fold the floats a bit out. The belts should be mounted **ONLY** around the centre hull **forward** of the forward crossbeam and **aft** of the aft crossbeam around the centre hull only. **Be careful not to get the belt around the sail drive and propeller or transducers.**
- 11) IMPORTANT If lifting straps are somehow damaged, they must NOT be used. Lifting straps must not be used after 5 years from purchase – use otherwise is at your own risk. Use only original Quick Link shackles supplied together with the lifting straps from Quorning boats in Denmark or other professional craning equipment.

SAILING TIPS

MANOEUVRING IN HARBOUR

If the water is deep enough always sail or motor with the swing keel fully DOWN for better manoeuvring and less drifting. The boat manoeuvres the same way in folded and/or unfolded position. Remember the boat is light and by stronger wind, the boat drifts easier than conventional yachts. Please note when the boat is folded in, it can be difficult to stop the boat, because the propeller is now up higher and closer to the water surface.

Get now used to manoeuvre the boat by engine, so you feel comfortable – also when motoring, do not go too slow. You must have enough speed to steer the boat which is normally 2 knots or even a bit more. The more you train this motor manoeuvring process, the easier and more comfortable (and fun) you will find handling the boat under power.

BOWTHRUSTER

If your boat is equipped with the optional Bow thruster, please remember that this is an electrical engine and cannot run consistent, use it only to adjust the bow position, and not for constant use, you can use it max 3-4 minutes – then let it rest a bit and then use it again. It will also automatically shut down when overheated.

Never motor faster than 5 knots with the foldable bow thruster in down position.

When using bow thruster, there must be NO lines in the water, like e.g. tack line from the bowsprit or mooring lines as these can get caught in the bow thruster.

No persons must be swimming near the boat when the Bow thruster is active.

When anchoring, we recommend shutting down the bow thruster on the fuse panel, so children cannot play with it (same goes for electrical deck winches).

Also, do NOT swim near the boat when the bow thruster is activated.

For further information, please read the "Owner's Manual" of the bow thruster.

ASSEMBLY OF THE DRAGONFLY 32 SWING WING

WINGS

First, mount the wings in respective places with the big pin bolts. The pin bolts must be mounted with the thread down, and the nut secured with a Cleves pin. Fold the wings out by holding the wings with a separate extra line diagonal forward.

FLOATS

Either lift the float up by hand (6 people) or better by forklift, crane or similar. When mounting the float to the wing – first place a washer and a nut on each bolt inside the Wing. Then tighten the nut at each wing by the big "key" No 32 just so that the floats lie against the underside of the wing, not tight! You must regularly look after and make sure that these are always tightened correctly. Before you mount the float, check that the thread on the float bolt is ok by installing a nut by hand only first, this can prevent big problems when installing the float to the Wings. Make also sure the thread is clean and has no sand.

WATERSTAYS

(the big heavy-duty cable from the centre hull and up the Wings)

There are two long water stays for the forward wings, and two short water stays for the aft wings. Make sure the thread is clean and use appropriate grease. The thread part of the water stay you turn into the big stainless-steel fitting in the end of the wing where the ama is mounted. Then you adjust the water stay so that the water stay is well hand-tight, it must not feel "loose". The water stays must be checked regularly to make sure they have the correct tension and are free from failures. Make sure that the threads are clean and have <u>no</u> sand grains. Use special grease for stainless when installing. Only adjust the water stay's when the floats are folded approx. 75 cm backwards. (The floats must be fitted (installed) on land before adjusting the water stays).

After the first season, the waterstays normally need only one full extra turn.

IMPORTANT: Waterstays must be changed every 7 years or by max. 15,000 NM of sailing.

ALWAYS assemble the boat on land. Never try and assembly or disassembly the boat on the water.

Rigging on the mast itself (spreader and diamond cables) must be changed/replaced by minimum every 15 years and or by max. 20,000 NM.

Safety cable under the trampoline is to be changed no later than after 10 years.

Side stays on the rigging + forestay should be changed after max 10 years or by max. 15,000 NM of sailing.

If the boat is equipped with wheel steering, we recommend changing these steel cables every 5 years or by max 10,000 NM.

Replace the dyneema halyards in the mast and reefing lines if you see chafing signs into the centre of the line.

For easier mounting of water stays use special stainless thread oil or thread grease in the thread. For easier adjusting of the water stays you can fold the wings back about 50 to 60 cm (2') aft and fit the water stays at this position and they will fit well hand tight, when back in forward position.

If Quorning Boats has adjusted/assembled the boat at the yard before delivery, the water stays normally need min ½ a turn after the first season/summer, maybe a full turn.

NETTING

The trampoline nettings are marked for either BB (port) or SB (starboard) mounting on the underside forward. Pull them into the netting tracks, starting from aft track alongside the cabin sides and then into the forward wings. The wire in the netting is fastened at the front outside wing by the quick link to the stainless eyebolt on "the wing fitting" – and at the aft wing/main hull connection by the stainless triangle fitting at the push pit base, mounted to the fork toggle terminal in the netting. The Swing-Wing cable by the outer end of the aft beam is mounted to the stainless block in the aft outer corner of the netting. Make sure the cable in the netting goes between the "wheel" and the pin bolt in the block. At the forward beam/hull assembly there is a shackle in the trampoline that <u>must</u> be secured to the centre hull – this is

<u>very</u> important. Check regularly that the outhaul cable is not damaged, as this effect the safety of the boat as well as the lines for the swing-wing system.

STEPPING THE MAST

When stepping the mast, if possible, one float should be folded out, which gives more working space and more clearance (slack) to fit the side stays.

You can fold the one side up against the dock, which is the most popular procedure though, so the boat is closer to the dock and the mast crane.

NEVER step the mast with both floats folded, as it is extremely difficult to fit the side stays and rigging, as everything is just too tight.

Remember to secure the rigging bolts in the side stays and forestay with Cleves pins and secure also with rigging tape.

Remember to install the Backstay lines and blocks before you motor away from the dock and set these lines just easy by hand only to avoid the rigging to move in the top from side to side.

FORESTAY AND SIDESTAYS

Forestay and side stays are mounted in the same fitting on the upper part of the mast, where the four upper diamond stays are. Each side stay is mounted with a 10 mm quick link and 12 mm quick link for the forestay that must be tightened hard with a wrench and best to secure with normal Locktite for better safety.

SETTING THE GENOA

Before hoisting the genoa, make sure to roll some furling line up on the furling drum. Turn the head- foil anti-clockwise until you have only about 2 metres (approx. 6 feet) line left in the cockpit. This way you are able to furl the genoa at once when the genoa is hoisted. The luff is mounted by the shackle over the furling drum. Tension is adjusted via the jib halyard. The genoa/jib halyard is fixed to the movable swivel at the head foil and the genoa top to the lower part of the swivel. Make sure the boat is folded out on both sides before setting sails.

MOUNTING THE MAINSAIL

The boat is folded out on both sides. The mainsail is placed on the one trampoline and start from the top of the sail. Hold the boat up into the wind. Mount the headboard (the top of the sail) into the top double Ronstan batten car on the mast. Then hoist the sail to the next batten and fit the next stainless bolt into the batten car with the nut on top etc. Use key no. 13 for the nuts on the batten cars.

Remember also to fit the two reefing lines in the sail as you mount the mainsail.

By taking the mainsail off again, **never** take off the Ronstan batten cars away from the mast track, all the balls will fall out – just loosen the 8mm nut on the batten car that is fixed to the batten pocket on the mainsail.

Only set the mainsail in calm wind conditions.

When the mainsail is up, you can easy install the single line lazy-jack system, which also works as a topping lift to hold up the mainsail boom. The lazy jack has only one line, please see a photo of the boat under sail which will easy show this.

IMPORTANT: The reefing line in the back end of the boom comes out from a sheave and through the block in the backend (leach) of the mainsail and is tied with a bolen knot forward of the main sail clew webbing, so it does not slide aft out of the rear boom end, this is VERY important.

REEFING LINES

The reefing lines are installed along outside the mast, check the reefing lines goes through the big stainless eye at the "Gooseneck" fitting (mast fitting to hold the boom to the mast). The reefing lines always stay in/on with the boom – also when the boom is taken away from the mast.

Deck plugs must be greased for better connection and to avoid corrosion. Important is to cover the deck plugs on the deck over the winter, when the plugs have been taken off, so these do not get any water inside.

Be careful the cables at the mast base does not get damaged or caught when stepping the mast AND remember to unscrew these from the deck plugs when taken the mast off the boat.

SAIL DIAGRAM - DRAGONFLY 32

DIAGRAM OF SAIL AREA TO TRUE WIND SPEED:

m/sec.	Knots	Beaufort	Upwind and beam reach	
0 – 8	0 – 16	4	Full main + full genoa	
8 – 10	16 – 20	5	Main 1 reef + full genoa	
10 – 12	20 – 24	5+	Main 1 reef + genoa 1 reefs	
12 – 14	24 – 28	6	Main 2 reefs + genoa 2 reefs	
14 – 16	28 – 32	7	Main 2 reefs + genoa 3 reefs	
16 – 20	33 – 40	8	Main 3 reefs + genoa 4 reefs	
20 – 24	40 – 47	9	Main 3 reefs + genoa almost or completely	
			furled – sailing upwind is now difficult	
25 – 28	48 – 55	10	Upwind sailing not recommended	
			- only with very good experience	

Beware that the mainsail has standard two cockpit-operated reefs only and that the third mainsail reef is optional on the Touring version and standard on the Supreme version.

m/sec.	Knots	Beaufort	Downwind lower than 120 degrees	
0 – 10	0 – 20	4	Full main + full genoa or spinnaker/Code 0	
10 – 12	18 – 22	5	Full main + full genoa (fx wing/wing)	
12 – 14	24 – 28	6	Main 1 reef + genoa 1 reef	
14 – 16	28 – 32	7	Main 2 reefs + genoa 2 reefs	
16 – 20	32 – 40	8	Main 2 reefs (or no main) + genoa 2 reefs (or less)	
20 – 24	40 – 47	9	No main + almost fully furled genoa	
25 – 28	48 – 55	10	No sails – maybe use of drift anchor or similar	

For a new inexperienced crew, we do not recommend sailing in more wind than max 20 knots or 4 Beaufort of true wind, before knowing the boat better!

IMPORTANT – If this diagram is not respected Quorning Boats ApS and dealers cannot be held responsible for boat, crew and/or gear. Beware that the boat can capsize if not handled correctly. For downwind sailing if "solid" seawater gets over the centre hull bow or float bow – this is the first warning to reduce sail. If winds are "gusty", make sure to be ready to release the sheets quickly – by holding the sheets in your hands.

If the leeward float is almost pressed down in the water to the deck level, this is time to reduce sail area.

Make sure that you know you can trust your wind speed device information and that you are fully sure if this wind device measures the wind speed in knots or m/s (meters per second) and if you see true or apparent wind speed on the display.

IMPORTANT – Asymmetric spinnaker or Code-O can **MAX.** be used beam reach safely up to 5 m/sec or 10 knots of true wind.

Code-O can **MAX.** be used upwind to 4 m/sec or 8 knots of true wind – use upwind in stronger wind, will damage either the boat or the sail.

Code-O and spinnaker can be used in stronger wind speed if used deeper downwind.

For more information about asymmetric spinnaker and Code-O, see further instructions for these sails under "Sailing and Trim guide".

Sailing and trimming guide

IMPORTANT – It is of great importance always to keep your sheets and halyards tidy when sailing because all lines come to the cockpit. This is a very important safety factor and improves the joy and pleasure of sailing for all on board.

TRIMMING THE GENOA

The luff tension is to be adjusted by the Genoa/Jib halyard. In light winds, of course only little tension just to avoid wrinkles along the luff. In more wind the luff needs more tension, but only to keep the luff tight, more is not necessary – over tensioning can damage the sail. <u>But</u> if you lose the luff tension too much, the Genoa halyard can be furled around the forestay and damage the forestay and can in worst case cause the forestay to break.

NEVER tighten the Genoa halyard with full load on the genoa sheets.

Under normal conditions the Genoa car on the cabin roof should be placed in the aft end of the track, approx. in the centre of the cabin top hatch. If the Genoa 'closes' in the aft leach, move the Genoa car a bit aft, and if the genoa "opens" further up in the aft leach, pull the Genoa car a bit forward.

On the Supreme version, you can adjust the Genoa car from the cockpit via the Genoa track outhaul on the halyard stopper, and the Genoa sheet goes through the halyard stopper marked as GENOA.

The "GENOA" halyard stopper is normally ALWAYS left open, and ONLY used if the winch is needed for another purpose. In case you need to put a reef in the Genoa you MUST pull the Genoa car forward for right trim. The Genoa itself has 2 marks on the foot of the Genoa, which is only to indicate 1 + 2 reef position on the furling Genoa.

For "reef 1" the Genoa car is pulled approx. 50 to 60 cm = 2' forward on the track approx. so the Genoa car is lining up with the halyard lead blocks, and for Genoa "reef 2" the Genoa car is pulled further forward 10–15 cm forward of the mast, if the Genoa is reefed more, the traveller is pulled approx. up to the forward end of the track. For your information, only use the barber haul system on beam reach or downwind, never upwind.

- To pull out the Genoa, always OPEN/release the furling line on its jammer/clutch on the cabin top by the other halyards. Then you just pull the Genoa sheet, and the Genoa will unfurl and be active.
- ONLY furl the Genoa when the Genoa sheet is released + also the barber haul control line.
- ALWAYS make sure you NEVER leave the boat before the Genoa furling jammer/clutch is 100% safe closed, so the genoa in windy condition does not roll out by itself, with no one on board, this can cause the boat to capsize in folded position.

MAST TRIMMING

The special Dragonfly carbon mast spreader system is always in trim and adjusted from the yard, but generally the mast must bend approx. 7 cm in the full length.

Do NOT change the trim of the diamond stays, as this can cause mast failure. The mainsail supplied by Quorning Boats is specially designed for this mast curve.

The mast curve looks a bit strange with no mainsail set, as the top of the mast looks like it bends forward, but with full mainsail set, the mast becomes a full nice mast curve – However when mainsail is reefed, the mast curve looks a bit strange but is normal for this mast design/construction.

USING THE BACKSTAY

The combined top shroud/backstay has been developed because of the Swing-Wing system to enable easy and quick trimming of the top shrouds/backstay's, when folding.

When sailing ALWAYS set the backstays in both sides to obtain the right tension on the top shrouds (side stays). In light wind, you can set them only easy and lock them in their jammers.

In more wind, set the backstays on the mainsheet self-tailing winch with the winch handle. In heavy wind, you set the backstays on the self-tailing winch as hard as you directly can, turning the winch handle by using one hand only

– never pull leeward backstay by force under sail. Only pull the slack leeward in by hand.

The backstay line can while sailing be stored in the aft cockpit locker, so you have less line on deck.

NEVER slack the backstay lines going downwind as this can/will damage the furling system and the forestay.

Downwind, we <u>strongly</u> recommend using a boomvang/preventer for better control of the roach on the mainsail and, so the mainsail does not chafe too hard on the leeward side stay.

REEFING THE MAINSAIL

Check the lazy jack line is secured in its cleat on the SB side of the boom (works also as topping lift). To reef the mainsail, you loosen first the mainsail sheet and thereafter the main halyard and it is recommended to mark on the main halyard where 'reef 1' and where 'reef 2' must be locked or fixed on the rope clutch (Constrictor). The main halyard is loosened/opened and released to its mark, and the reef line is pulled hard so that the reefing block by the luff is approx. 15 cm = 6" above the boom.

IMPORTANT - when reefing the mainsail, continue upwind by the genoa, and ease off first completely the main sheet, then the main halyard is loosened till the mark reef 1 and then you pull the line reef 1 which is marked on port jammer/clutch. This line will then automatically reef the luff first and then the leach. Same procedure applies to reef 2 and the reverse when reefing out. After each reef the sail can be 'packed' with chock cords for less wind resistance, not a must.

Pulling the reef line, procedure is completed when the reef block in the aft leach is touching the boom. Check that the reefing block forward at the mainsail luff is approx. 10 or max 15 cm (4" to 6") over the mainsail boom.

Check that the reefing block at the luff is not chafing the sail. Normally, it does not, but sometimes you must go up and "arrange" the sail at the luff.

On the Dragonfly 32, there are only two big reef positions in the main sail. For Ocean crossing we recommend a third reef in the main sail on the Touring version, the Supreme version always have 3 reefpoints in the mainsail if supplied by the yard.

For long distance sailing, we recommend preparing a reefing line from the extra third reef on the mainsail down to reef II, so you easier can control the third reef by hand. When using the third reef, the conditions are of course not the easiest.

Please avoid reefing downwind, as the mainsail can be blown past on forward of the side stays and break the battens. Of course, if there is no other way out, you can do it – but this is not to be recommended.

MAIN SAIL

The mainsail needs much more trimming than on a monohull, especially on the mainsheet as the boat has many speed potentials, depending on the wind speed. This calls for concentrated trimming if you want maximum speed and fun with your boat. Generally, the leach seen from the backend of the mainsail boom end to the mast top must be almost straight, no matter what wind force: the roach must under no circumstances 'fall out' or twist unless the boat is pressed too hard. Trimming the main in a breeze takes great effort for maximum performance but makes sailing more fun.

If the mainsail overpowers the boat upwind, just ease the mainsail traveller approx. 15 - 20 cm to leeward (6"-8").

Going upwind in stronger wind conditions we also recommend opening the mainsheet.

By tacking upwind against waves – we recommend easing the mainsheet and or the main traveller to make an easier tack – if the mainsail is too tight – the boat will too quickly go into the wind again and it is hard to finish a tack procedure, here it is also vital that the genoa is being pulled in tight quickly.

TACKING

When tacking with the boat, it sometimes helps to ease off the mainsheet a little (especially in strong winds and waves). If you stall the boat after a tack, it also helps to ease the mainsail until the boat builds up speed again. If the boat starts to go backwards after a tack, then immediately turn the rudder blade reverse to windward, this helps the bow to bear off again and get wind into the sails again. Do not turn the rudder to 'normal' again until the boat starts moving forward again.

MAINSAIL FOOT

Is trimmed normally. Light wind when tacking, light curve approx. max. 12 cm = 5'. Downwind, big curve. Medium air tacking, flat foot. And downwind, large curve. Hard wind tacking, flat foot max. 10 cm = 4', and downwind also flat foot - this has little effect only and it is much more important to focus using main sheet and preventer (boomvang). We at the yard normally set and adjust the foot in only ONE and same position approx. 7 cm curve (3") always.

MAINSAIL LUFF TENSION

In light wind, you set the main halyard easy only to avoid "wrinkles" in the sail, which has the effect that you easier can help the mainsail flipping over when tacking, so that the battens are turned right for the new tack. We would here recommend accepting a few ringlets in the mainsail luff.

In medium air the main halyard is tightened even harder, so that the wrinkles in the mainsail are gone and the luff straight.

IMPORTANT

In heavy winds the main halyard is tightened quite hard to flatten the sail and avoid wrinkles in the luff – luff wrinkles can sometimes not be avoided. By tensioning the mainsail luff upwind in winds exceeding 6 m/s (12 knots), you must ease off the main sheet when tensioning the luff.

If for example you are anchoring or beaching for a short time with the main sail set, then loosen the main halyard a bit to release the tension in the mainsail luff, and the mainsail will not so easily catch the wind.

In stronger wind conditions wrinkles, cannot be avoided in the mainsail luff, just too must power – BUT you can e.g. use the reef no. 2 line at the luff by tying the reef 2 line to the webbing in the mainsail and use the reef 2 line as a Cunningham – this way you can better control the luff of the full mainsail.

MAINSHEET TRAVELLER CAR

Multihulls have normally a rule that goes: the mainsheet car must NEVER pass the centre line to windward. If the wind is increasing when tacking upwind and you find the mainsail has too much power and whether helm, try and ease out the traveller, approx. 10-15 cm = 4-6" to leeward instead for slackening the mainsheet and therefore not make the mainsail deeper. Doing

this the boat can take more wind without reefing. Eventually you can also ease off the sheet and "open" the roach further up in the mainsail.

IMPORTANT – when jibing in stronger wind conditions, make sure to make a fully controlled gibe, which means, set the traveller car in the centre and pull the mainsheet fully in centre, as you gibe. After gibing, quickly ease off the mainsail sheet again and set the boomvang/preventer again. If you are not careful when gibing in strong winds, you can damage the mainsail or, even worst case, the rigging.

If you have wheel steering system – it is even more important to make controlled gibing – as the mainsheet can catch the wheel pedestal and damage this – so this calls for even more focus when gibing in stronger winds.

SETTING AND FIXING THE BOWSPRIT

The optional bowsprit must be set manually.

You go forward and open the anchor locker – you push by hand the bowsprit forward – check the tack line is always loose when this is done – when the bowsprit is out of the tube in the port side of the anchor locker, you pull the bowsprit towards the centre, and you fix the bowsprit in its position fitting that you clearly see back in the anchor locker – and now you fix the bowsprit with the stainless pin in the stainless fitting – and now **very IMPORTANT** – the SB side bowsprit support line is automatic fixed at all times – whereas you HAVE to remember to lock the port bowsprit side support by the aft forward wing. If the bowsprit is not fixed here – the bowsprit will brake immediately or even, make serious damage to the centre hull.

Remember to also bring in back the bowsprit before you fold in the hulls again and at the same time pull the tack line tight again, so this does not get caught by the bow thruster.

ASYMMETRIC SPINNAKER SAILING

Sailing with the asymmetrical spinnaker is a fantastic third dimension in sailing, which a lot of people dread, caused by bad earlier monohull experiences. On a trimaran, asymmetric spinnaker sailing is fun and a comfortable adventure. A trimaran is not heeling over from one side to the other (rolling), and the spinnaker pole is non-existent. With a little practice,

you can handle the spinnaker alone but always handle it with respect!!! If you respect the spinnaker and use it with reason it is great – also when cruising.

SPINNAKER SHEET

Is led from the cockpit to the block on the outer top middle of the aft wing and directly <u>inside</u> the top shroud/side stay to the spinnaker clew and "inside" between the spinnaker luff and the forestay. This is best and prevent the sheet from falling in the water in front of the boat.

SETTING THE SPINNAKER

You can best set the spinnaker either from the leeward trampoline or directly from the leeward float hatch. Make sure the lines run correctly, that the spinnaker halyard for example is not twisted round the forestay or the diamond spreader. IMPORTANT – keep sailing downwind and hoist the spinnaker in the sock behind the mainsail in the big "wind shade" downwind.

CAUTION – If you feel any resistance hoisting it or sheeting it, stop pulling immediately. Pull up the spinnaker to the halyard sheave box and then pull or set the spinnaker sheet, so the spinnaker does not get air too early, not tight, and now pull up the sock, when the sock is about half way up – pull out the tack to the bowsprit – then pull up the rest of the sock and fix the line you pulled up the sock with, just somewhere convenient on the mast or on a halyard on the deck.

Then luff up a bit, and when the spinnaker fills up, roll up the genoa. It is very important that your spinnaker fills first, or you will find yourself furling the spinnaker into the genoa. It never pays sailing with both genoa and spinnaker at the same time.

GIBING WITH SPINNAKER

Go fully downwind and KEEP the mainsail here, DON'T pull over the main yet – pull over the endless spinnaker sheet, so you now see the spinnaker clew 2-3 metres (6 feet) on the windward side and now SLOWLY jibe the mainsail, while you keep pulling the spinnaker sheet – you will see that it works perfectly. Important is to start pulling over the spinnaker <u>before</u> you jibe the mainsail. If you sail alone – pull the spinnaker full to windward before you gibe.

For downwind sailing like 160-170 degrees, we recommend to pull the tack of the spinnaker to windward, by using the windward genoa barberhauler line that you find on the foredeck of the float – fix the barberhaul line to the tack of the spinnaker and with the barberhauler you can now release the tack line and pull the spinnaker to windward to the windward float, but downwind make sure to have 60 to 70 cm distance between the flatbow and the spinnaker. Only use this system for longer distance downwind.

Sailing downwind, it is a perfect course if you line up the Windex arrow with the leeward Windex marker/arm (the Windex have two arms facing back) this way you will find that you are sailing basically 160 degrees downwind – which is the best you can do when the spinnaker is pulled to the windward float.

TAKING DOWN THE SPINNAKER

NEVER sail the spinnaker without main sail!!! It can become very difficult and dangerous to get it down without the wind shade behind the mainsail.

If the wind increases, it is a bit more difficult to take down the spinnaker. Practice can eliminate this problem. Prepare the spinnaker halyard and tack line and the sheets so that these lines can "run" out without any problems.

Bear off to full downwind, ease out the mainsheet and fix the mainsail boom with the preventer/boomwang. Now pull the spinnaker sheet tight in behind the mainsail – and you will see that the spinnaker completely has no wind and no pressure because of the wind shade from the mainsail –

Now slacken/release the bowsprit tack line completely off first, and the spinnaker now easy fly back and automatically in behind the mainsail like a flag- yes and even in stronger winds it will do this - now from the trampoline netting you pull down the sock close behind the mainsail, this is very easy and is no stress.

This way you can control the spinnaker, easily and elegantly. Now you can ease off the spinnaker halyard and pull the spinnaker and sock down. Do not ease off faster than it is pulled down controlled, so it does not drop into the water.

NEVER ease off the leeward spinnaker sheet when taking it down.

IMPORTANT - ALWAYS gibe "between" forestay and luff of spinnaker and bowsprit.

Spinnaker sailing is great and fun, BUT and again BUT always make sure you have enough water and space to leeward, so you always can go more downwind if the wind increases and so you always have enough water and space to go downwind and take down the spinnaker in no stress – if you don't have enough water and space to leeward, this can get you into a lot of trouble – this is the only real important thing to always make sure is ok when sailing with the spinnaker –enjoy it ©.

Normally, we recommend downwind course approx. 160° with a jibing angle of 40° - in stronger winds it pays of well to go even deeper downwind. For longer downwind course, pull up the centreboard halfway or even full up.

CODE - O

This is a fantastic but a VERY powerful sail. Only use this upwind in light airs like upwind in max 4 m/s (8 knots) true wind. Upwind in light airs you will only be able to point like 50 to 55 degrees and when tacking upwind you must furl the sail in – tack – and furl out again.

Going upwind you need to sheet close to the main hull on the "inside" aft beam there is a padeye for the Code-O.

IMPORTANT – On the SUPREME version never set the Code-O with the tack line system on the bowsprit – use the free top stainless eye you see just over the side support stays and the waterstay – here you install the Code-O furler directly in this steel eye which also prevent the furling system to turn around when furling.

So, when setting the Code-O, pull in the bowsprit, and fix the furler to this steel eye and pull out and set the bowsprit again. On the TOURING version, the tack line sets the Code-O.

Pull up the Code-O, for the TOURING version use the spinnaker halyard and for the SUPREME version there is a special Code-O halyard available and must be used – do not use the spinnaker halyard as this is set too high for the Code-O on the mast. Remember to install the Code-O sheet before hoisting the sail.

Set the Code-O luff tight and make sure to immediately install the endless furling line system, which you lead back on the boat and fix this with the chock cord on the furling line were convenient. When the endless furling line is in position – make sure to fix the one furling line that now is furling the Code-O, either on the forward mooring cleat by just one turn around the cleat or even more simple just fix it with one turn around one of the forward lifting eyes. This is **very important**, so you avoid the Code-O to furl out.

To furl out the Code-O, just release or open the furling line and pull the Code-O sheet – and you are now sailing.

Going beam reach, maybe use both sheets on the same side, this way you have one sheet in the Code-O sheet block and the other sheet in the spinnaker block, this way you can better adjust the sheeting more open or closer – works well.

FURL IN THE CODE-O

NEVER furl the Code-O when going up into the wind – **ALWAYS** furl the Code-O in when going downwind – this makes it much easier and safer. Again, remember to "lock" the furling line.

To make the furling system better work overtime – always furl the Code-O in the same direction – this is better for the torsion Code-O luff line.

ANCHORING

The anchor bracket is designed for max 16 kgs anchor.

Use chain (8 mm diameter) or 14 mm rope with internal lead up front. Recommended length of anchor line should be 5-10 times the depth – depending on the depth and the condition of the seabed.

PRECAUTION - Before anchoring check first the weather forecast. Thereafter the depth of water, current and nature of the seabed.

By beaching or drying out the boat beware of rocks and stones, **ONLY** beach the boat on clean sand.

When anchoring, we recommend securing the anchor line to one of the front mooring cleats and to make a bridle, which you can fasten on the U-type big stainless padeye on the front of each forward wing. Using a bridle prevents the boat from "fishtailing". This bridle is each side approx. 6 to 7 meters long.

ALWAYS anchor in protected areas!!

Note that multihulls have more windage than conventional yachts.

By anchoring off the stern, the engine should be stopped to prevent the anchor line from getting into the propeller.

IMPORTANT – if your Dragonfly 32 is equipped with a bowsprit, pull first back in the bowsprit, before you set the anchor, as this does conflict.

The anchor is close to the bow, so be careful the last bit when the anchor comes out of the water and up to the anchor fitting.


When using anchor and chain via windlass in + 15 knots wind we recommend using a chain hook with a line, so the windlass is not in function. The electric anchor windless is not designed to hold strong force – please read the manual for the windless – windless is optional and therefore not installed on all boats.

When using the anchor and the windlass system from the centre hull bow, it is very important after launch to check that anchor has grip, to setup an anchor bridle on the anchor line.

A trimaran always fish tale a lot (moves a lot from side to side) and to prevent this, you install a line from each forward wing (beam), not on the float, but from the bigger stainless U-bolt on the wing out by the float. Here, you fasten a line approx. 6 to 7 meters and fasten or tie to the anchor line from both sides. This way, the boat will stay stable when resting at anchor.

The reason why this is so important, is because the boat fish tale so much, which can damage the stainless anchor fitting and bend this.

If you are not able to make an anchor bridle, then move the anchor line up to the cleat you use for normal docking. When anchoring from the centre hull without a bridle, the bowsprit must be pulled in, as the anchor line will catch the bobstay going down to the lower part of the bow.



Angel of heel Degree M x T framom gniftlgiR

DRAGONFLY 32, Loaded Displacement Condition, Righting moment

Centreboard and rudder kick-up system CENTREBOARD

The centreboard has been constructed in such a way that even the slightest touch of ground makes it kick up automatically, via the special release cleat on the port cabin top aft. After this has released, to put it back in position, just push down the folding cleat by force again and it will go back in active position again.

Generally, when using the boat by engine or sail, we always recommend placing the centre board all the way down. On a longer course beam reach halfway down will also do fine and sailing downwind pull it fully up in normal conditions. In stronger winds never pull it more than halfway up.

IMPORTANT — do remember, though, lowering the centreboard before going upwind again. Under sail pressure you **CANNOT** possibly adjust the centreboard neither up or down, you will have to either luff into the wind or bear off to dead downwind to adjust the centreboard. Downwind you will seldom find adjusting problems.

By trying to pull the centre board down while sailing, you can break the blocks or control lines to the centre board system.


The centreboard, if fully down, when the knot on the "board up" line on SB-side is touching the lead eye — <u>never</u> change the position of this knot, as this adjusts the position of how far down the centreboard max can go down safely. Please see centreboard diagram.


<u>Always</u> make sure that the "board up" line is released when pulling the board down.

When craning the boat, remember to pull the centreboard up and fix the "board up" line in this cam cleat.

To take out the centreboard, the boat must be in a crane. Lift the centreboard up and unscrew the stainless bolt on the front of the centreboard, you can now lower the centreboard slowly and the centreboard will drop out of the centreboard casing. Please see drawing below.

To install the centreboard is the same procedure in reverse.





Rudder system

The rudder also has a kick-up system, so by hitting the ground the rudder will always kick up. The downhaul line and release cleat are placed on the stainless rudder head fitting.

IMPORTANT – Be sure that the rudder is always fully down in position, otherwise the rudder gets hard weather helm. To pull it hard down, take the rudder downhaul line up to the SB mainsheet winch and pull the rudder downhaul line a bit hard and secure and push by your fingers the rudder downhaul line, while it is under load, into the release cleat on the top of the rudder fitting.

Maybe mark the line so you can easy visually check the rudder is fully down – again this is very important.

Do regularly check the downhaul is ok and not damaged. The rudder system is **NOT** designed to be used while sailing in no other position than fully down, otherwise the rudder system will bend and become loose or even break off.

To pull up the rudder, first release the downhaul line and pull the lifting line in the back. Also, regularly check the bolt where the rudder is bolted to the rudder head, that this nut is tight.

Always make sure that the downhaul line is always ready to release with no kinks or knots on the line and that the line can be led into the aft locker via the drain hole.

When e.g. beaching the Dragonfly, just beforehand release the downhaul line fully, so the rudder goes up by itself when it touches the ground and then pull it up, it is a big rudder and not designed to go easy up and down like on a dinghy.

The automatic quick release cleat can be adjusted lighter and/or harder, if needed.


If the rudder is bolted too tight, it can be difficult to move it up and down – just bolt it easy tight, so there is no slack sideways in the rudder.


Boats with wheel steering are equipped with an extra external emergency tiller to be fitted just over the rudderstock, in the backend cockpit floor. The emergency tiller is to be found on the bulkhead in the engine compartment.


We recommend leaving the rudder in the water when moored in the marina, and this is no problem as the rudder is treated with antifouling.


Rudder-system


Dragonfly 32













Hull-fittings Dragonfly 32 Shower outlet Shower bilge pump outlet Intake toilet 1/2" Air vent Air vent for the holding tank Watermaker out Outlet from optional watermaker Toilet sink drain Above waterline Saltwater intake

Watermaker in

Intake for optional

Speed/depth transducer, in aft. cabin

Cooling water

Intake for cooling


water for diesel


engine

Transducer

watermaker

Outlet anchor room Clamshell drain from the anchor compartment Outlet holdingtank Black water from the holdingtank via the manual pump to sea, 1 1/4" Air vent Air vent for the water tank, above waterline Deck outlet





Maintenance and product information

Engine type:		
Engine No:		
Gelcoat hull colour.		
Gelcoat deck colour.		
Gelcoat non-skid colour.		
Propeller.	Туре	Size
House bank batteries:		
Engine battery:		
Epoxy barrier under water.		
Antifouling brand:		
Mast colour No:		

INFORMATION ABOUT PRODUCTS USED FOR DRAGONFLY

WOODWORK

The Elm woodwork in the cabins is varnished with two-part satin varnish. To varnish again, sand with grit 240 or finer sandpaper. You can use either one or two component varnish with satin finish. Two-part varnish is best.

As regards to the standard lighter colour woodwork, all interior panels are made of High-pressure laminate panels glued to high quality Marine grade plywood panels. These laminate panels are extremely robust and take no maintenance besides normal cleaning. These panels we call "Ash" as we use real Ash wood for all the wooden trim inside the boat and this wooden trim is also varnished with a two-part varnish and please read above our recommendation how to varnish this.

COMPOSITE

Dragonfly is built of hand-laid, reinforced fibreglass and polyester/vinylester resin combined with 15-20 mm PVC sandwich foam core with closed cells, which do not absorb water. Therefore, the boat is unsinkable at all times, as this foam core has the same function as life jacket.

For repairs use ONLY products based on polyester/vinylester basis. Epoxy can be used in an emergency but cannot be cosmetically improved later with gelcoat.

If repairs are done where gelcoat finish is not needed (like under the waterline) or if the finish needs painting – epoxy resin is to be recommended.

Before any lamination repairs are done, the repaired area must be completely dry.

ELETRONICS

By delivery of a new boat from Quorning Boats, the yard does not calibrate electronic equipment in detail, only standard setup calibration.

It is the responsibility of the skipper/owner to ensure that all the electronics are fully functional after first delivery and reliably calibrated.

BATTERIES

When replacing the onboard batteries, **ALWAYS** replace them with the same type, brand, and size of batteries. The electronic system on your boat is set up and designed especially for the type of batteries installed specifically on this boat.

Please see the overall diagram for position of batteries aft – midship and forward.

For Lithium batteries change – **always** contact a professional, as this technology changes quickly over a short time and new calibration software might be needed.

Never install fluid batteries.

SPRAYHOOD, COCKPIT TENT AND BIMINI

Please take note that the sprayhood and cockpit tent is **ONLY** designed to be used under normal conditions and is **NOT** designed as a cover or protection for winter storage nor protecting the boat during windy and stormy conditions and by heavy snow or rainfall conditions.

THRU-HULL FITTINGS AND SEA VALVES

- The sea valves are closed when the handle is across the sea valve.
- An annual visual inspection of all sea valves on the boat should be performed to ensure they appear normal. There should always be two clamps on the hoses attached to sea valves below the waterline.
- An annual manual physical test should be performed to ensure all sea valves are functional and can be closed by hand without the use of tools.
- It is recommended that sea valves are always closed on the boat and only opened when in use.
- It is recommended to replace thru-hull fittings and sea valves when the boat is 15 years old.

MAINTENANCE

Dragonfly 32 Touring, Supreme and Evolution

To inform and illustrate recommended service, maintenance, and refitting on an older Dragonfly, we have drawn this general information sheet. Rough elements, like strong winds and wave conditions, strong saltwater and UV do have some impact on the boat after a long sailing life.

We strongly recommend servicing and changing vital parts on your boat according to our recommendations. This information overrules any other former information you may have, as the following is based on updated knowledge.

EXCHANGE INTERVALS OF STRUCTURAL PARTS

Dragonfly 32 Touring, Supreme (built since 2012), and Evolution (built since 2019)

- Waterstays every maximum 7 years or 15.000 NM.
- Side stays and forestay cable every maximum 10 years or 15.000 NM.
- Beam stop cable to forward, outside beam under trampoline every 10 years or 15.000 NM.
- Diamond spreader stays on the mast every maximum 15 years or 20.000
 NM.
- Structural Dyneema line in backstay every maximum 7 years.
- Halyards and Dyneema lines need regularly visual check for wear and tear.
- Steering wheel cables every maximum 5 years or 15.000 NM. Regular visual control is recommended and especially before planning longer trips.
- Safety cables every maximum 15 years. Regular visual control is strongly recommended.

The above list of exchange intervals is the recommendations from the Quorning Dragonfly Yard and is not an extension of the 2-year warranty committed from when the boat was new.

From January 2024 we engrave the Dragonfly logo including a production year, on all rigging terminals on structural cables such as waterstays, side stays and diamond cables, to make it easier for you as a customer to follow the above recommended exchange intervals and to be sure correct material has been used.

IMPORTANT: Always check very carefully that you replace cables in the same type of cable quality if not ordered/replaced by the Dragonfly Yard.

RIGGING

Always visually check the rigging, halyards, reefing lines, water stays and rudder downhaul line, as well as the cables and lines operating the Swing-Wing system.

Minimum once a year, shorten all halyards, reefing lines, and Swing-Wing lines by approx. 20-25 cm, but only if you see chafing on the lines. After several years, you can turn them around or replace the lines.

Visual check of all cables is still required when changing the rigging. We strongly recommend focusing on side stay cables, as these easily bend when stepping the mast. Bended side stay cables near the terminal may cause the side stay cable to break.

On all Dragonfly Trimarans, please regularly check the forestay cable in the top by the terminal. When furling, the spinnaker or Code-0 halyard may block the forestay, which can cause failure of the forestay.

When changing to new parts and rigging systems – ALWAYS make sure to use the same kind of products and or order these parts from Quorning Boats After Sales at the Dragonfly Yard in Denmark.

Never climb the rigging when the boat is in folded position.

Tension on the rigging, please see the rig diagram.

NEVER change the tension on the diamonds stays on the mast without checking tension with a tension meter according to rig tension diagram. Changing the rig tension can cause the mast to break.

GENERAL INFORMATION

NEVER drill holes in the carbon mast section without asking your local dealer or Quorning Boats beforehand.

NEVER wrap the mast in any kind of plastic, as this will cause the paint to bubble. If wrapping is needed, use breathable textile. Best to leave it open.

TRAMPOLINES

On all Dragonfly Trimarans, we recommend re-stitching (sewing) along the seams of the trampolines every 6-7 years (in climates with strong UV, every 5 years). Normally, our clients change their trampolines after 10-12 years use.

Please note this is a recommendation and it is still always the skipper's responsibility to regularly check the condition of the trampolines. This is quite important for the safety of you and your crew.

FLOAT DECK TEFLON PAD RINGS

The white 5 mm Teflon pad rings on the float deck under the wings, need to be changed every 13-15 years – this is neither critical nor structural. For easy change of these pads/rings, you just bolt off the floats from the wings by the one bolt in each end of the Wing/beam. Use crane or forklift to hold the float while doing this.

QUICK-LINKS

Over decades, Quorning Boats has been using the riggings links, so-called "Quick-Links", in the Dragonfly rigging production. When replacing these, it is of **utmost importance** to purchase links of same high quality or similar products carrying same strength (working load). Many products look the same, but do NOT carry the same strength. If you are not sure about this, please contact your local dealer or the Quorning Dragonfly Yard.



1 The above picture shows a Quick link from Peguet that is used on all Dragonfly's.

PAINTING

Caution for all painted surfaces on the boat and mast

Painted surfaces may not be covered with Plastic or other non-breathable materials, as water and condensation cannot be lead away from the painted surfaces, and these are not able to dry.

When water is stuck between the Paint and a non-breathable or non-ventilated material, blisters can occur between the paint and the gelcoat or the carbon sections of the mast.

Due to these circumstances, the permanent use of Ex. Matt-Fenders cannot be recommended, as water and Condensation can also get stuck between these and the hull, and lead to blisters in the Paint.

Quorning Boats cannot be held responsible for Blisters in the paint occurred due covering the painted surfaces with non-breathable materials.

ORDERING PARTS

Original parts can be ordered at Quorning Boats at <u>aftersales@dragonfly.dk</u> Common spare parts can be shipped within two weeks, whereas special parts and/or custom-made parts usually are served within 6-8 weeks.

IMPORTANT - Parts ordered at Quorning Boats Denmark, will be produced in originally designed materials. Should you choose to order from other suppliers, please always check that the same kind of materials are used – especially on the waterstays and other rigging parts, where stronger Dyeform cables and fittings are needed.

BY ANY DAMAGE TO THE BOAT

Contact your dealer or the yard for instructions. If not, you could endanger your safety and/or maybe even lose your warranty.

GELCOAT REPAIRS

IMPORTANT – Successful repairs require dry weather and a temperature between +15° to max 30 degrees C.

- Ratio of hardener is min 2% and max 3%.
- Gel setting time is approx. half an hour.
- Never work in direct sun when applying gel coat or any resin repairs.

HOW TO MAKE GELCOAT REPAIRS:

- First sand the actual repair with grit 80.
- Then sand the area around it with grit 180 240.
- Apply gelcoat by 2 or 3 layers.
- When completely dry sand it down with 120 240, thereafter with 500 800 – 1,200.
- After that polish with rubber compound and finally wax the whole area.
- Use lots of ventilation, gloves, glasses, and dust mask.
- Keep children away.

WARNING

- The catalyst is a dangerous product and should not be left within children's reach.
- Avoid contact with skin.
- In case of contact, wash with soapy water and rinse liberally.

Clean all tools with acetone.

GENERAL SERVICING

- Clean blocks and sheets well in freshwater regularly.
- Lubricate blocks and halyard stoppers every 2-3 months.
- Clean all tracks frequently where travellers are functioning. Also, the mast track.
- Min once a year clean and grease the winches and check the springs.
- Always keep the sails covered when not in use to protect from the sun.
- Keep the sails dry and rinse regularly with freshwater. If sails get damaged immediate repair is required.
- Let a sail maker check the sails once a year.
- Have the engine serviced min once a year and according to the manufacturer.
- Be sure to have antifreeze cooling on the engine.
- Check that all sea corks are working well.
- Empty water and holding tank before the winter.
- Empty the hot water boiler before the winter.
- Check engine oil.
- Check diesel fuel filter.
- Check zinc on propeller and engine shaft.
- When the boat is not used for some time e.g. like over winter, fill up the diesel tank 100% and ask locally if diesel needs special extra treatment.

- Make sure always to keep the Teflon rings on the float decks clean. Often rinse this with just water. If they start squeezing (making noises), spray these with Teflon spray every now and then.
- Check that all lines look to be ok.
- Check that the handles on the hatches are not loose. If so, just tighten the screw on the "inside" of the handle.
- Once a year unscrew the float Moonlight /skylight handles (not the flush hatches) take it apart and on the outside fitting you see a smaller O-ring – this needs grease once a year.
- Check the seams on the trampolines and the cables on the trampolines and the Swing-Wing system is ok. Any sailmaker can repair the trampolines.

Please note that this is only our simple and basic recommendation on what to check and service – there might be other special products on your boat that also needs attention and service.

SPRING CLEANING

EXTERIOR

Wash and wax the boat. (Do not wax the non-skid areas).
Waxing is not needed if the boat was waxed just before the winter storage.

- 1) It is recommended that all blocks, batten cars are greased with Teflon type spray or e.g. the best is Mc-Lube from Harken.
- 2) Mast, boom, and head foil must be washed and cleaned. If you do not immediately succeed in cleaning the aluminium, you can use polish cream.
- 3) Wash and rinse the batten cars well, incl. the mast track.

INTERIOR

Clean the boat everywhere with a vacuum cleaner and best with a rag from a bucket of warm water.

ANTIFOULING

Main hull – First, wash the bottom of the boat with freshwater. If necessary, wash with high-pressure. Let it dry fully out and apply antifouling with a lacquer roll – best is to sand easy the antifouling surface first.

This information does not apply for boats with Coppercoat.

The centreboard normally has enough antifouling for the first 3 to 4 seasons. You will then have to lift the boat with a crane, to clean and antifoul the centreboard.

Coppercoat only needs high-pressure cleaning, and if the boat stays in the water, clean the Copper coat surface 2 or 3 times a year by hand with e.g., a sponge to clean pots. Use the green "sanding" part on the sponge or sandpaper grit 180 or finer.

BLOCKS, BATTEN CARS ETC.

It is recommended that all blocks, batten cars are washed in freshwater and when dry greased with Teflon type spray or e.g., the best is Mc-Lube from Harken.

Wash and rinse the batten cars well, incl. the mast track.

MAST, BOOM, SPREADERS ETC.

Mast, boom, and head foil must be washed and cleaned. If you do not immediately succeed in cleaning the aluminium, you can use rubber compound polish cream.

CLEANING UP FOR THE WINTER

You are recommended to wash the boat completely clean, wax and polish all surfaces except the non-skid areas.

Make sure to take off the sails, sprayhood, and cockpit tent. Wash and rinse out dirt and salt. Everything must be completely dry, before stowed away for the winter and kept in a dry place.

CUSHIONS

- For cleaning cushions, you can remove the cover by unfastening the zip on the back of the cushion.
- For washing or dry-cleaning, check which material your cushions are made of, before cleaning.
- It is best to store the cushions in dry surroundings.
- If the cushions stay inside the boat set them up vertically.

Various steel wires can be washed in warm soap and water, rinsed clean, dried, and afterwards wiped with an oilcloth.

All ropes and blocks should be washed in warm soap and water, rinsed and dried.

RIGGING AND BOOM

- Make sure all lines and halyards are intact. Should a halyard have a failure at the end, turn it over.
- Every year all halyards and reefing lines should be shortened approx. 25
 cm. only if you can see chafing marks.

The water tank must be emptied and cleaned – it is easily accessible in the front cabin under the V berth.

During the winter, open all lockers for best ventilation and make sure that the boat is well ventilated.

THE ENGINE

Please contact your local engine dealer.

The marine batteries can stay in the boat over the winter. But better charge them full before the winter and charge them up once a month.

Dry out the hulls completely to avoid frost damage and check all bilges in all 3 hulls are dry, also the forward and aft bilges in the floats.

Make sure that ventilation is good before storing the boat for the winter. The best thing to do is to store the boat indoors for the winter period, if you use a canvas or plastic type cover make sure it does not touch the boat and hulls as this might scratch the boat.

Flush the holding tank and empty this before you haul out the boat – best min. two times.

Any damages and lacks on boat, sails or instrumentation should be fixed in the autumn; everybody can give the best service at that time of the year.

IMPORTANT INFORMATION ON THE RIGGING

Always check the rigging, halyards, reefing lines, water stays and rudder down line, as well as the cables and lines operating the swing-wing system.

Minimum once a year shorten all halyards, reefing lines, and swing-wing lines by pprox.. 25 cm. After some years, you can turn them around or replace the lines.

Water stays we recommend changing every 7 years using the same quality of products, or at max. 15,000 NM.

Side stays should be changed latest after 10 years or by max 15,000 NM.

Diamond stays on the mast should be changed latest after 15 years or by max 20,000 NM.

Never climb the rigging when the boat is in folded position.

Tension on the rigging, please see rig diagram.

Never change the tension on the diamonds without checking tension with a tension meter according to rig tension diagram, changing the rig tension can cause the mast to break.

Never drill holes in the carbon mast section without asking your local dealer or Quorning Boats beforehand.

NEVER wrap the mast in any plastic, as this can cause the paint to bubble. If wrapping is needed, use breathable textile.

We recommend changing the trampolines after 10 years in strong sun climates and elsewhere after max 12 years.

IMPORTANT INFORMATION ON THE ENGINE

INBOARD ENGINE

- Check zinc on the sail drive every 6 months.
- Sail drive rubber gasket must be changed every 7 years.
- Service engine according to the manufacturer's service programme.
- Always check that the engine gets cooling water by checking visually that the exhaust has water coming out.
- Always keep a spare impeller and drive belt on board.
- · Check the level of oil.
- Check the level of cooling water in the engine and the plastic bowl.
- Always make sure to have antifreeze in the cooling water in cold climate.

IT IS <u>ALWAYS</u>

THE OWNER'S AND/OR THE SKIPPER'S RESPONSIBILITY

TO CHECK THE CONDITION OF THE BOAT AND GEAR

AT ALL TIMES, TO ENSURE THE SAFETY OF THE BOAT AND CREW.

We wish you some great and fantastic sailing with your Dragonfly 32, and if you respect what is informed in this Owner's Manual you will enjoy and understand the boat even better.

We wish you happy sailing and great fun!

Quorning Boats ApS DRAGONFLY TRIMARANS DENMARK

Rope diagram


Dragonfly 32 Swing Wing Touring Version

Text	Material	No of lines	Diameter	Length in metres
Main sheet	Polyester	1	10 mm	30 m
Backstay	Polyester	2	10 mm	20 m
Backstay	Dyneema /			4.4 m
with eye-splicing in both ends	Carbon	2	8 mm	incl. eye-splicing
Genoa sheet	Polyester	1	12 mm	24 m
Main traveller outhaul	Polyester	1	8 mm	14 m
Genoa traveller outhaul	Dyneema	2	8 mm	13.5 m
Asymmetric spinnaker sheet	Polyester	1	10 mm	46 m
Genoa furler	Dyneema	1	10 mm	18 m
Tack line	Dyneema	1	8 mm	20 m
Swing Wing line	Dyneema	2	8 mm	27 m
Barberhaul	Polyester	2	8 mm	26 m
Centerboard up	Dyneema	1	8 mm	10 m
Centerboard down	Dyneema	1	8 mm	12 m
Preventer/boomvang	Polyester	2	8 mm	15 m
Lazy-Jack	Polyester	1	6 mm	18 m
Lazy-Jack on spreader	Polyester	2	6 mm	2.5 m
Mooring lines	Polyester	4	16 mm	14 m
Main halyard	Dyneema	1	8 mm	51 m
Genoa halyard	Dyneema	1	10 mm	35 m
Spinnaker halyard	Dyneema	1	10 mm	38 m
Reef 1	Dyneema	1	8 mm	20 m
Reef 2	Dyneema	1	8 mm	34 m

Rope diagram

Dragonfly 32 Swing Wing Evolution Version

Text	Material	No of lines	Diameter	Length in metres
Main sheet	Polyester	1	10 mm	30 m
Backstay	Dyneema	2	10 mm	20 m
Backstay	Dyneema /			4.4 m
with eye-splicing in both ends	Carbon	2	8 mm	incl. eye-splicing
Genoa sheet	Polyester	1	12 mm	24 m
Main traveller outhaul	Polyester	1	8 mm	14 m
Genoa traveller outhaul	Dyneema	2	8 mm	13.5 m
Asymmetric spinnaker sheet	Polyester	1	10 mm	46 m
Genoa furler	Dyneema	1	8 mm	18 m
Tack line	Dyneema	1	8 mm	20 m
Swing Wing line	Dyneema	2	8 mm	27 m
Barberhaul	Polyester	2	8 mm	26 m
Centerboard up	Dyneema	1	8 mm	10 m
Centerboard down	Dyneema	1	8 mm	12 m
Preventer/boomvang	Polyester	2	8 mm	15 m
Lazy-Jack	Polyester	1	6 mm	18 m
Lazy-Jack on spreader	Polyester	2	6 mm	2.5 m
Mooring lines	Polyester	4	16 mm	14 m
Main halyard	Dyneema	1	8 mm	57 m
Genoa halyard	Dyneema	1	10 mm	36 m
Spinnaker halyard	Dyneema	1	8 mm	41 m
Code 0 halyard	Dyneema	1	8 mm	38 m
Reef 1	Dyneema	1	8 mm	20 m
Reef 2	Dyneema	1	8 mm	35 m



OWNER'S LIST

First owner:	
	Name:
	Address:
	City:
	Country:
	Date of purchase:
Second owner:	
	Name:
	Address:
	City:
	Country:
	Date of purchase:
Third owner:	
	Name:
	Address:
	City:
	Country:
	Date of purchase:

Keep this manual in a safe place onboard and hand it over to the new owner, if you sell the boat!!

Warranty

INBOARD ENGINE REGISTRATION:

Your inboard engine has been registered from the yard to the engine manufacturer or importer. For warranty and/or service, contact your local engine dealer.

RAYMARINE AND ELECTRONICS:

If Raymarine or possible other electronics has been mounted on your boat, Quorning Boats has registered the serial numbers according to your hull number for warranty.

HOW TO PROCEED WITH WARRANTY CLAIMS ON ELECTRONICS:

You must contact your local Raymarine or whatever brand of electronics is used directly, referring to your instrument registration.

RAYMARINE:

Please contact your national agent or Raymarine distributor. They will be able to inform the nearest Raymarine Service.

Please take note that only basic and standard calibration has been made on your electronic system from the yard.

GPS is not delivered with detailed electronic charts from the yard.

VICTRON:

The Victron system has been locked in 'User' mode by Quorning Boats ApS to prevent accidental and unwanted changes to the configuration.

The Victron system can be unlocked to 'Installer' mode. Installer has additional privileges and once changed from default requires a password.

The password to unlock 'User' mode can be requested by contacting Quorning Boats ApS directly.

Disclaimer – If the Victron system is unlocked, Quorning Boats ApS disclaims any responsibility in connection with setup, configuration and functionality.